


# Associate an Additional Remote Control to a Powerlouvre™ Window or Remote Receiver Unit

Call 1 800 777 758 for further assistance.

Please have both your existing Remote Control (already associated with the Powerloure™ Window) and your new Remote Control (unassociated) at hand and read through the entire instructions before you begin.

Existing Remote Control

figure one



1

## Prime the Existing Remote Control

Turn the existing Remote Control over, you will notice a small hole about half way down on the right (figure one).

Insert a thin, stiff object (a straightened paperclip is ideal for this purpose) and push down on the button for 1 second.

Turn the existing Remote Control over and press the OPEN button for 1 second (figure two).

Existing Remote Control

figure two



2

## Match the Open Function on the New Remote Control

Within two seconds of completing Step One press the OPEN button on the New Remote Control (figure three).

If you were unable to complete Step Two within 2 seconds of Step One, repeat Step One and Step Two again.

New Remote Control

figure three



3

## Match the Toggle Function on the New Remote Control

Repeat Step One.

Within two seconds of completing Step One press the TOGGLE button on the New Remote Control (figure four).

If you were unable to complete Step Three within 2 seconds of Step One, repeat Step One and Step Three again.

New Remote Control

figure four



4

## Match the Close Function on the New Remote Control


Repeat Step One.

Within two seconds of completing Step One press the CLOSE button on the New Remote Control (figure five).

If you were unable to complete Step Four within 2 seconds of Step One, repeat Step One and Step Four again.

New Remote Control

figure five



*breezway*™  
light · air · space